DOOGEE

X90L

Thanks for choosing DOOGEE products

www.doogee.cc

For user manuals, please go to the official website of DOOGEE and enter the product name in the search bar to download the corresponding manual.

DOOGEE Global | DOOGEE_Japan | DOOGEE_Official

Follow us on Facebook

Get Started

Thank you for choosing DOOGEE smart phones. In order to ensure your device is in the best condition, please read the user manual carefully before using it.

File Transfer

PC-iPhone File Transfer

Once the phone is connected to a PC via USB, the PC will charge the mobile phone automatically.

1. Drag the notification panel down and tap "USB charging this device".
2. Select "Transfer files".
3. The device is recognized as a removable disk by the computer. You can open the disk to view, copy and transfer files from your phone to PC and vice-versa.

Note:

1. **Use USB to**
   - **Charge this device**: Just charge the phone
   - **Transfer files**: Transfer files between phone and other devices
   - **Transfer photos (PTP)**: Transfer photos if the PTP is not supported by PC
   - **Use device as MIDI**: Use the device as MIDI
2. Some operating systems or devices may not support some file formats or file transfer function. Please use other operating systems or devices instead.

Keys and Parts

The phone includes many parts, Camera, Flash Light, Earpiece, Speaker, Microphone, Charging Port, as shown in the below diagram for more using details.

Keys	Directions
1. Volume up button	Press the upper key to raise the volume and the lower key to lower the volume.
2. Power key	Press and hold for 3s to turn on/off the phone. Press and quick tap to lock the screen.
3. Volume down button	Press the lower key to lower the volume.
4. Front Camera	To take selfie or video chat by the phone camera.
5. Headset interface	To connect an earphone to listen to music or calls, use the earphone.
6. Rear Flash	Flash light for photo taking.
7. Micro SD	Insert a micro SD card (optional).
8. Micro Sim	Insert a micro SIM card (optional).
9. Rear Cameras	Rear camera for photo taking.
10. USB Interface	To connect charger or USB cable to transfer data.
11. Rear Speaker	To play calls.
12. Fingerprint	Fingerprint sensor.
13. Earpiece	To hear calls.
14. Microphone	To make a call or record voice.

Lock and Unlock the Screen

- **Lock the Screen**
  1. Press the "Power" key to lock the screen. The screen shall be automatically locked after it is not used for a while.
- **Unlock the Screen**
  1. Press the "Power" key to light up the screen.
  2. Drag the "Padlock" icon of the screen to unlock the screen.

Change Screen Lock

1. On the home screen, select "Settings" > "Security" > "Screen lock".
2. Choose the screen lock method.

Notification Panel

Notification allows the status bar report the new arrival of messages, calendar events, alarm etc. You can switch on/off Bluetooth, Wi-Fi, Mobile data etc.

Icons	Descriptions	Icons	Descriptions
	Battery		Mobile Data
	Wi-Fi		Bluetooth
	Airplane Mode		Flashlight
	Location		Autorotate
	Do not Disturb		Eye Protection

Change Wallpaper

Three ways to set up personalized wallpaper:

1. Press and hold any empty space on the screen, select "Wallpaper".
2. Path: "Settings" > "Display" > "Wallpaper" > select a picture > "Apply".
3. "Gallery" > choose a picture > "Set picture as" > "Wallpaper".

Make a Call

Make a Call Directly

1. On the home screen, touch the icon "Phone" to display the dialing keypad.
2. Touch the numeric keys to input the telephone number and click the icon "Call" to make a call.

Make a Call From Contacts

1. On the home screen, touch "Contacts" to select the one you want to call, and then touch the phone number to make a call.

Make a Call From Call Logs

On the home screen, touch "Phone" > "" > select a call from call logs and click it to make a call.

Note:

If you have inserted two SIM cards to the phone, there will be two call icons on the dialing interface. Choose SIM 1 or SIM 2 to make a call.

Reject a Call by Sending a Busy Message

When you are inconvenient to answer an incoming call, you can send a busy message for rejecting it.

1. On the incoming call interface, drag the message icon to the upper direction to reject the incoming call.
2. Tap one of them to send out and then the call will be rejected.

Add a Contact

1. Enter "Contacts" on the desktop, touch the icon to select the storage location.
2. Fill the new contact information and save.

Messaging

Send a New Message

1. Enter "Messages" > "Start chat" > "To" > "Enter the first recipient's number or name" > "Enter a message".

Receive a New Message

When there is a new message comes, an icon will appear in the notification bar to notify you. Slide the status bar down to open the notification panel. Or go to "Messaging" to read the new message directly.

Editing SMS and MMS

1. You can compose a new SMS by cutting or copying text.
2. Press and holds a text SMS, select copy and paste it into the entry space of new message having entry a phone number.

Delete

The selected contact is highlighted in Green.

1. A SMS may contain video, picture, audio etc.

Step:

1. Enter the new message having title/text > tap "Attach" > select Picture, Video, Audio or Slideshow > choose corresponding file > tape the text and phone number of the receiver > send it.

Browser

Open Browser

1. Enter "Browser" on the desktop, touch "Browser".
2. Touch the input field at the top of the screen to input a website address.
3. Tap the icon "".

Browser Options

When browsing a web page, you can slide to scroll the screen to view other parts of the web page.

- Touch the icon "" > select "Save to bookmarks" to add the current web page as a bookmark.
- Touch the icon "" > select "Bookmarks/History" to open the saved bookmarks or pages you've browsed.
- Touch the icon "" > select "Share page" to share the website with others.

Browser Settings

On the browser interface, touch the icon "" > select "Settings" to operate setting according to the instruction.

Note:

You must have a mobile data or Wi-Fi connection to access the Internet.

Enjoy Music

You can listen to the music saved in your phone through the music player.

When you copy music files to your phone, the music player searches the device for the files and builds a catalog of your music.

Download Applications From Play Store

1. Sign in to your Google Play Store account.
2. Enter the "Play Store" > search or browse account > select or install the APP you need.

Manage Applications

Enter "Settings" > "Apps". Then you can navigation to view the information, and also you can force the app to stop working or uninstall it.

Maintenance and Safety

Please read this safety information carefully so that you can use your phone in safe condition.

1. Around children

Keep the phone out of reach of children and your phone. It could also contain a number of detachable parts, which constituting these little parts may cause asphyxiation.

2. Hearing damage

Prolonged listening at very high volume may damage your hearing. Please reduce the volume to the lowest possible level when listening to music or having a call.

3. Fire hazard

Do not leave your phone near heat sources such as microwave oven, stove or heater. Do not place your phone near flammable materials as there is a risk of fire.

4. Hit a gas station

Do not use your phone at gas station. In fact, it's always a good idea to switch off whenever you're near fuels, chemicals or explosives.

5. Contact with liquid

Do not expose the phone to liquid or touch it with wet hands, since damage caused by water may be irreparable.

6. Do not destroy the battery and charger

Do not use a battery or charger that has been damaged. Do not short circuit the battery. Do not throw the battery or charger into a fire. Do not dismantle battery and destroy it permanently. As a general rule, you should not use battery that is over 5 years old. Keep the temperature of battery (For example, in hot summer) or temperature may reduce service life.

7. Shocks and Impact

Protect your phone from shock and impact. Some parts of the phone are made from glass and might break if the phone is dropped or hit. Do not use the phone if the glass on the phone and touching the screen with sharp objects.

8. Maintenance

Do not try to disassemble your phone as there is a risk of electric shock. Do not use any chemical solvents or cleaners as it is dirtch (do not use a solvent, such as benzene or alcohol).

9. Temperature

Your phone should be in the environment at low high of temperature. Do not place the mobile phone in burning sun or totally wet surrounding. The suitable temperature for the phone is 0°C to 40°C.

EN

Overview

Overview

Package Contents

USB Micro USB Cable | Charger | Protective Film | User Manual

Battery

EN5L includes a built-in battery.

You can track your battery status with the icon showed on the top right of the screen.

Warning

Use only authorized approved batteries specifically designed for your phone. Incompatible batteries can cause serious damage to your phone.

Never place batteries or phones in contact with heat sources such as radiators, microwave ovens, or stoves. Batteries may explode when overheated.

Accessories

Correct card installation

You can install two Nano SIM cards and one TF card.

How to insert SIM card:

1. Ensure the device is power off.
2. Use the ejector pin to open the SIM card tray by inserting it into the provided pin hole.
3. Place the Nano SIM card or TF card into the SIM card tray.
4. Insert the SIM card tray back into the phone.

Caution:

Only Nano SIM card or TF card is supported by this device.Don't insert by other sizes SIM card.

Overview

Device parameters

Display	6.1" HD
Color	Black, Silver, Green, Phantom Purple, Emerald Green
Operating system	Android™ 9 Pie
Processor	MT6761 (Helio A22, up to1.5GHz)
GPU	IMG GE8100
RAM	3GB

ROM
Battery
Rear Cameras
Front Camera
Connectors (I/O)
Sim Card Slots
Media Formats
Audio
Image
Dimensions
Weight
Thickness
Screen Size
Screen Resolution
Pixel Density
Screen Ratio
Screen Material
Sensor
Camera Pixel
Aperture
Flash
Video
Resolution
Frame Rate
Connection
Bluetooth
Wi-Fi
Navigation
Charging Port
Charging Mode
Charging Time
Charging Power
Fingerprint Sensor
Face Recognition
Speaker
Microphone
Vibration
Headset Port
Sensor
Camera
Flash
Speaker
Microphone
Charging port
Charging port
Fingerprint
Rear Camera
Rear Flash
Rear Fingerprint
Volume +
Volume -
Power key
Charging port
Charging port
Charging port