USER MANUAL

DENVER PLO-108 outdoor power plug

www.denver.eu

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Keep product out of the reach of children and pets to avoid chewing and swallowing.
3. Product operating and storage temperature is from 0 degree Celsius to 35 degree Celsius. Under and over this temperature might affect the function.
4. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
5. This product is for IPX4 which means it is protected from splashing water, no matter the direction. The product is not protected from water jets at any direction or immersed in to water.
6. Do not expose to heat or direct sunlight!
7. The direct plug-in adapter is used as disconnect device, the disconnect device shall remain readily operable. So, make sure there is space around the power outlet for easy access.

This outdoor plug is IP44 water proof. Please make sure to use outdoor cable as well.
1.Get started
Download the app called "DENVER SMART HOME" on your smart phone. It is available on Appstore and Google play. The app will ask you to register a user. Please do this by using your email address, and then log into the app.
You will be asked to create a "family". This is to make it easy to have several systems in the app at the same time. Now you need to add the power plug to the app. First, connect it to your power outlet and turn this on. Then press the on/of button for 5 seconds until the indicator flashes quickly. Push "Add Device" or + in top of app, and choose "socket", and follow on screen instructions. It will guide you through the whole setup.

Now the power plug is connected and you can make timers, countdown timers, different automatisations etc. within the app. Please notice, there are two ways to add the power plug to your system. EZ mode and AP mode. EZ mode are the easiest, but if you haveproblems using that, the app will guide you through the AP mode instead. In this case, just follow the in-app instructions.
2.Daily use
In your home screen of the app you can now find your power plug. Push this and you will get to power plug page. Here you can turn on, turn off, make timers etc.
3.Amazon Alexa & Google assistant
It is possible to use the power plug with Amazon Alexa & Google assistant. Use the app to add this function. Instructions are shown in the app.
If you by any means need to reset the power plug, this is done by pushing the on/off button 5 seconds. Now you can set it up from start again.
Input Voltage: AC 230V/50Hz
Output: 16A Maximum 3680W
Wireless Type: 2.4GHz
App Support: iOS/Android
Please notice - All products are subject to change without any notice.
We take reservations for errors and omissions in the manual.
ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S

www.denver.eu

Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type PLO-108 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.denver.eu and then click the search ICON on topline of website. Write model number: PLO-108. Now enter product page, and red directive is found under downloads/other downloads.
Operating Frequency Range: 2.4G(2412 MHZ - 2472MHZ) Wifi 802.11 b/g/n
Maximum radio-frequency power : 20 dBm

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.facebook.com/Denver.eu

Sicherheitshinweise

Bitte lesen Sie die Sicherheitshinweise vor der ersten Verwendung des Produkts aufmerksam durch und bewahren Sie die Anleitung zum späteren Nachschlagen auf.

1. Dieses Produkt ist kein Spielzeug. Bewahren Sie es außerhalb der Reichweite von Kindern auf.
2. Bewahren Sie das Produkt außerhalb der Reichweite von Kindern und Haustieren auf, um ein Verschlucken von Kleinteilen zu vermeiden.
3. Die Betriebs- und Lagertemperatur des Produkts liegt zwischen 0 und +35 °C. Eine Unter- oder Überschreitung dieser Temperatur kann die Funktion beeinträchtigen.
4. Öffnen Sie das Produkt nicht. Das Berühren der Elektronik kann zu einem Stromschlag führen. Reparatur- und Wartungsarbeiten dürfen nur von qualifiziertem Personal durchgeführt werden.
5. Dieses Produkt ist Schutzart IPX4, was bedeutet, dass es vor Spritzwasser aus allen Richtungen geschützt ist. Das Produkt ist nicht gegen Wasserstrahlen aus allen Richtungen geschützt und darf nicht in Wasser eingetaucht werden.
6. Setzen Sie es nicht der Hitze oder direkter Sonneneinstrahlung aus!
7. Wenn das Steckernetzteil als Trennvo rrichtung verwendet wird, muss die Steckdose jederzeit leicht erreichbar sein. Achten Sie darauf, dass um die Steckdose herum ausreichend Platz für einfachen Zugang ist.

Dieser Stecker für den Außenbereich ist wasserdicht nach IP44. Bitte stellen Sie sicher, dass Ihr Kabel für den Außenbereich dies ebenfalls ist.
1.Erste Schritte
Laden Sie die App „DENVER SMART HOME" auf Ihr Smartphone herunter. Sie finden sie im App Store und bei Google Play.
Die App fordert Sie auf, sich als Benutzer/-in zu registrieren. Registrieren Sie sich mit Ihrer Mailadresse und melden Sie sich anschließend bei der App an. Sie werden anschließend aufgefordert, eine „Familie" zu erstellen. Dadurch wird es für Sie einfacher, mehrere Systeme gleichzeitig in der App zu führen.
Als nächstes müssen Sie in der App die Steckdose hinzufügen.
Schließen Sie sie hierfür zuerst an Ihrem Stromnetz an und schalten Sie sie ein. Drücken Sie dann ca. 5 Sekunden lang die Ein/Aus-Taste solange, bis die Anzeige-LED schnell blinkt.